


## How to Guide - Replacing Toner

### Replacing a Toner Cartridge




1 | Open the side door.



2 | Remove the used toner.

Unpack the new toner cartridge.



3 | Insert the new toner cartridge until it clicks into place.

Close the door.